


PARTS LIST

In the unlikely event you are missing any components please call 0117 934 1790 and state the name of the product, size and description of the item. i.e. Classic Monet Pergola Matt Black 1.2m, End Plug.




AGRIFRAMES, Journal House, Hartcliffe Way, Bristol, BS3 5RJ
ORDERS (0)117 934 1790 **FAX** (0)117 934 1791 **ORDER ONLINE** www.agriframes.co.uk

Agriframes™

Assembly Instructions for Classic Monet Pergola Matt Black

Product Code: 30434-TBK & 30435-TBK



Please read the assembly instructions carefully prior to construction.

Tips:

Positioning of the horizontal bar

In many cases the position of the Cross Poles is down to personal preference. However, if you have the lattice option you will need to leave the correct distance between bars.

On the bottom section the Cross Poles need to be at least 3 inches above the base of the tube.

Tips:

Cross Poles

Before positioning the Cross Poles on the uprights, half screw in the grub screws to the ring clamps on the spacer bars, to reduce the risk of losing the screws. Once correctly positioned tighten the grub screw to secure the spacer bar to the uprights.

Lattice Panel Option

For illustrative purposes we have only shown one side fixed with the lattice panels. Attach panels to both sides as you proceed.

Issues:

If you are experiencing any issues with your Agriframes product please contact our customer services team on 0117 934 1790 and quote your order reference.

WARNING: small parts, tools and plastic bags. Keep children away until the unit is assembled and everything is cleared away.


NOTE: the card, paper sack, and polythene bags are recyclable - please dispose of carefully

MISSING PARTS PROCEDURE: please call our customer service team on 0117 934 1790 and quote your order reference and quote the missing part. *E.g. ASO-----, 2 uprights missing.*


CLASSIC MONET PERGOLA MATT BLACK

STEP 1


* LATTICE INFILL



STEP 2



STEP 3



STEP 4



*

ONLY FOR ORDERS WITH LATTICE PANELS. PANELS CAN BE ORDERED FROM www.agriframes.co.uk

Assembly Instructions for Classic Monet Pergola Matt Black

Please read these instructions carefully.

Assembly requires: a Rubber Mallet, an Allen Key (provided), a ladder, spirit level and a tape




Figure 1: Monet Pergola Cross Pole Positioning on the Monet Curves.

Step 1:

- Before assembly check the Pergola cross poles to ensure the grub screws are inserted into the holes on the ring clamps.
 - Loosen these grub screws $\frac{1}{2}$ way out of the hole, to ensure when the ring clamps are moved into position the grub screw does not scratch the outer coating of the metal.
- Slide a moisture seal over the reduced ends of the 3 Monet Curves and connect the plain ended curves to the reduced ended curves. Then cover the join of the curves with a moisture seal.
- Slide a small moisture seal over the reduced end of the Part B Pergola Cross Poles.
- Insert Part B of the Cross poles into the non-reduced ends of Part A of the Cross Poles, to create a long Pergola Cross Pole, cover the join between the poles with a moisture seal.
- Slide a long Pergola Cross pole onto the Monet Curves on the outside of the curves.
 - Starting with the top Pergola Cross Poles, these poles should be positioned towards the join of the curves. Once you are satisfied with the Cross Poles position tighten the grub screw.
 - The second Pergola Cross Pole needs to be placed 40" below the top Cross Pole, to allow for the lattice infill as illustrated in Figure 1. This may require the second cross pole to be positioned on the join between the curve and the upright.
- Attach the endplugsto the ends of the Pergola Cross poles, which are attached to the Monet Curves.
- **Attach the lattice using the cable ties, once the ties are secured trim the excess.**
- Once the top of the Pergola has been completed move the structure to where it is to be installed and, firmly push the structure into the ground to make an impression, indentation or mark to indicate where the uprights should be placed. Then remove the top structure and check that the marks can clearly be seen.

Step 2:

- Using the hole-maker make a hole 13" into the ground, where you have marked or indented the ground previously, ensure that the holes are vertical and to the same depth.

- Insert the end plugs into the non-reduced ends of 6 uprights and insert these uprights into the ground where you have made the holes, with the end plugs going into the soil. Slide a long Pergola Cross pole down the uprights to the ground, do not tighten the grub screws, you will need to position the cross pole shortly.
- Slide a moisture seal over the reduced end of the poles and then connect the remaining 6 uprights. Cover the join between the poles with a moisture seal.

Step 3:

- Once the uprights have been inserted and connected, slide one of the Pergola Cross Pole to each set of the uprights. Once you are satisfied with the Cross Poles Position tighten the grub screws. Repeat this action with the other Cross Pole on the opposite uprights.
 - If you have chosen the lattice option you will need to position the Cross Poles, on the uprights, approximately 40" away from one another, as illustrated in Figure 2, to accommodate the lattice infill.
 - If you are not using lattice the positioning of the Pergola Cross Poles can be adjusted to suit, however there needs to be two Cross Poles on each set of uprights and two Cross Poles on the curve to ensure that the structure is stable.
- **Attach the lattice using the cable ties, once the ties are secured trim the excess.**

Step 5:

- Lift the constructed Pergola top onto the completed uprights, cover the joins with moisture seals.
 - You will need at least 2 people for this step due to the weight of the Pergola top.




Figure 2: Positioning of the Cross Poles on the Uprights

If you have any questions regarding assembly please call our customer service team on 0117 934 1790